

Time - Precision

TP600

GSM MODEM CLOCK INSTALLATION

- 1) Remove the lid from the modem box and fit the modem box to the wall using the four corner mountings.
- 2) Fit the clock to the wall using the three keyhole mountings, just to the left of the modem box. Feed the ribbon cable through the round hole in the back of the clock. (If you have to leave a gap between the two units, the ribbon cable should be protected using some appropriate trunking).
- 3) Connect the mains out from the modem box to the mains in of the clock and secure the mains lead with the cable clip provided.
- 4) Switch the power on and the clock should count down and run through the modem setting procedure. The signal strength is displayed in the top right corner of the display. Anything below 10 is considered a weak signal and anything 5 or below could not work.

